T0600T "h9252660



FIG. 1

MOST RECENTLY USED FRAME DATABASE -- 200

	FRAME LOCATION
1	
2	
3	
...	
N	

FIG. 2


350
access counter
shift
300
"lock"
320-0
330-0
1
a
b
0-locked
frame 0
accessed
310-0
320-1
330-1
1
a
b
1-locked
frame 1
accessed
310-1
320-m
330-m
1
a
b
m-locked
frame m
accessed
310-m

FIG. 3

T0600T "H9252660



FIG. 4

FRAME MISS COUNTER -- 500

FRAME LOCATION	FRAME MISS COUNTER
0	01
1	10
2	00
...	
N-1	10

FRAME UNLOCK SIGNAL

FIG. 5